


m-cro

better urban lifestyle



Micro Cable Lock

AC3001B / AC4114 / AC4115



m-cro



DK - Vejledning

Skift koden før brug. Standard-koden er 0-0-0 .

1. Tryk kabel-enden (1) ned i låsen.

2. Vælg en ny kode.

Tryk på kabelknappen (2) for at styre kablets længde eller for at åbne låsen.

m-cro

Micro Mobility Systems AG
Bahnhofstrasse 10
8700 Küsnacht/ Switzerland

Micro Scooters Ltd.
110 Coast Road
West Mersea
Colchester
Co5 8NA
UK

Micro Mobility Systems Deutschland
GmbH
Fuhrmansstrasse 7, 72351 Geislingen,
Deutschland

www.micro-mobility.com
© 2024 Micro Mobility Systems AG
All rights reserved.



Made in China 01/2023